

Co-55: Injection, Adult Male

T(d)	- 24 h Excretion -		Retention			
	Fecal	Urine	Liver	Skelton	GI-Tract	W body
0.0	0.00E+00	0.00E+00	1.00E-01	7.00E-02	7.00E-02	1.00E+00
1.0	3.37E-03	9.39E-02	1.06E-01	2.58E-02	1.50E-02	2.45E-01
2.0	3.41E-03	7.54E-03	3.20E-02	1.01E-02	5.60E-03	8.37E-02
3.0	1.36E-03	2.24E-03	9.77E-03	3.89E-03	1.76E-03	2.88E-02
4.0	4.37E-04	6.74E-04	3.04E-03	1.48E-03	5.25E-04	1.01E-02
5.0	1.31E-04	2.06E-04	9.62E-04	5.56E-04	1.56E-04	3.55E-03
6.0	3.98E-05	6.52E-05	3.12E-04	2.08E-04	4.66E-05	1.27E-03
7.0	1.18E-05	2.06E-05	1.03E-04	7.75E-05	1.41E-05	4.61E-04
8.0	3.57E-06	6.64E-06	3.51E-05	2.88E-05	4.33E-06	1.68E-04
9.0	1.10E-06	2.18E-06	1.22E-05	1.07E-05	1.35E-06	6.19E-05
10.0	3.37E-07	7.20E-07	4.30E-06	3.96E-06	4.28E-07	2.29E-05
15.0	1.41E-09	3.95E-09	3.15E-08	3.03E-08	2.00E-09	1.83E-07
30.0	2.57E-16	8.89E-16	1.57E-14	1.14E-14	3.87E-16	8.35E-14
45.0	1.33E-22	3.02E-22	9.51E-21	5.97E-21	9.40E-23	4.66E-20

Co-56: Injection, Adult Male

T(d)	- 24 h Excretion -		Retention			
	Fecal	Urine	Liver	Skelton	GI-Tract	W body
0.0	0.00E+00	0.00E+00	1.00E-01	7.00E-02	7.00E-02	1.00E+00
1.0	8.63E-03	2.40E-01	2.72E-01	6.61E-02	3.84E-02	6.26E-01
2.0	2.24E-02	4.94E-02	2.10E-01	6.63E-02	3.67E-02	5.49E-01
3.0	2.29E-02	3.75E-02	1.64E-01	6.53E-02	2.94E-02	4.83E-01
4.0	1.87E-02	2.89E-02	1.30E-01	6.34E-02	2.25E-02	4.32E-01
5.0	1.44E-02	2.26E-02	1.06E-01	6.11E-02	1.71E-02	3.91E-01
6.0	1.10E-02	1.81E-02	8.77E-02	5.86E-02	1.31E-02	3.58E-01
7.0	8.43E-03	1.47E-02	7.45E-02	5.59E-02	1.01E-02	3.32E-01
8.0	6.52E-03	1.21E-02	6.47E-02	5.31E-02	7.96E-03	3.10E-01
9.0	5.12E-03	1.02E-02	5.74E-02	5.05E-02	6.35E-03	2.92E-01
10.0	4.08E-03	8.73E-03	5.19E-02	4.79E-02	5.16E-03	2.77E-01
15.0	1.68E-03	4.78E-03	3.83E-02	3.69E-02	2.32E-03	2.23E-01
30.0	4.44E-04	1.56E-03	2.77E-02	2.00E-02	6.59E-04	1.47E-01
45.0	1.88E-04	6.94E-04	2.27E-02	1.41E-02	2.84E-04	1.10E-01
60.0	1.01E-04	3.88E-04	1.92E-02	1.13E-02	1.54E-04	8.73E-02
90.0	4.51E-05	1.81E-04	1.40E-02	8.33E-03	7.01E-05	5.83E-02
180.0	8.66E-06	3.52E-05	5.40E-03	3.66E-03	1.36E-05	2.00E-02
365.0	6.46E-07	2.66E-06	7.49E-04	6.74E-04	1.02E-06	2.88E-03

Co-57: Injection, Adult Male

T(d)	- 24 h Excretion -		Retention			
	Fecal	Urine	Liver	Skelton	GI-Tract	W body
0.0	0.00E+00	0.00E+00	1.00E-01	7.00E-02	7.00E-02	1.00E+00
1.0	8.68E-03	2.42E-01	2.74E-01	6.65E-02	3.87E-02	6.30E-01
2.0	2.26E-02	5.00E-02	2.13E-01	6.72E-02	3.72E-02	5.56E-01
3.0	2.33E-02	3.82E-02	1.67E-01	6.65E-02	3.00E-02	4.93E-01
4.0	1.92E-02	2.96E-02	1.34E-01	6.51E-02	2.31E-02	4.43E-01
5.0	1.49E-02	2.34E-02	1.09E-01	6.31E-02	1.77E-02	4.03E-01
6.0	1.14E-02	1.88E-02	9.11E-02	6.09E-02	1.36E-02	3.72E-01
7.0	8.82E-03	1.54E-02	7.79E-02	5.84E-02	1.06E-02	3.47E-01
8.0	6.87E-03	1.28E-02	6.81E-02	5.59E-02	8.38E-03	3.26E-01
9.0	5.42E-03	1.08E-02	6.08E-02	5.35E-02	6.73E-03	3.09E-01
10.0	4.35E-03	9.31E-03	5.54E-02	5.10E-02	5.50E-03	2.95E-01
15.0	1.85E-03	5.26E-03	4.22E-02	4.06E-02	2.55E-03	2.46E-01
30.0	5.38E-04	1.89E-03	3.36E-02	2.43E-02	7.99E-04	1.78E-01
45.0	2.50E-04	9.26E-04	3.04E-02	1.88E-02	3.79E-04	1.47E-01
60.0	1.48E-04	5.71E-04	2.82E-02	1.67E-02	2.27E-04	1.28E-01
90.0	8.04E-05	3.22E-04	2.49E-02	1.49E-02	1.25E-04	1.04E-01
180.0	2.75E-05	1.12E-04	1.72E-02	1.16E-02	4.30E-05	6.37E-02
365.0	6.72E-06	2.77E-05	7.81E-03	7.03E-03	1.06E-05	3.01E-02

Co-58: Injection, Adult Male

T(d)	- 24 h Excretion -		Retention			
	Fecal	Urine	Liver	Skelton	GI-Tract	W body
0.0	0.00E+00	0.00E+00	1.00E-01	7.00E-02	7.00E-02	1.00E+00
1.0	8.62E-03	2.40E-01	2.72E-01	6.61E-02	3.84E-02	6.26E-01
2.0	2.23E-02	4.93E-02	2.09E-01	6.62E-02	3.66E-02	5.48E-01
3.0	2.28E-02	3.74E-02	1.64E-01	6.51E-02	2.93E-02	4.82E-01
4.0	1.87E-02	2.88E-02	1.30E-01	6.32E-02	2.24E-02	4.30E-01
5.0	1.44E-02	2.25E-02	1.05E-01	6.09E-02	1.70E-02	3.89E-01
6.0	1.10E-02	1.80E-02	8.73E-02	5.83E-02	1.30E-02	3.56E-01
7.0	8.38E-03	1.46E-02	7.40E-02	5.55E-02	1.01E-02	3.30E-01
8.0	6.48E-03	1.21E-02	6.43E-02	5.28E-02	7.91E-03	3.08E-01
9.0	5.08E-03	1.01E-02	5.70E-02	5.01E-02	6.31E-03	2.90E-01
10.0	4.05E-03	8.66E-03	5.15E-02	4.75E-02	5.12E-03	2.74E-01
15.0	1.66E-03	4.72E-03	3.79E-02	3.64E-02	2.29E-03	2.20E-01
30.0	4.33E-04	1.52E-03	2.70E-02	1.95E-02	6.44E-04	1.43E-01
45.0	1.81E-04	6.69E-04	2.19E-02	1.36E-02	2.74E-04	1.06E-01
60.0	9.58E-05	3.70E-04	1.83E-02	1.08E-02	1.47E-04	8.32E-02
90.0	4.19E-05	1.68E-04	1.30E-02	7.75E-03	6.52E-05	5.42E-02
180.0	7.49E-06	3.04E-05	4.67E-03	3.16E-03	1.17E-05	1.73E-02
365.0	4.81E-07	1.98E-06	5.58E-04	5.02E-04	7.57E-07	2.15E-03

Cr-51: Injection, Adult Male

T(d)	- 24 h Excretion -		Retention		
	Fecal	Urine	Skelton	GI-Tract	W body
0.0	0.00E+00	0.00E+00	7.00E-02	7.00E-02	1.00E+00
1.0	1.70E-02	1.14E-01	5.36E-02	1.20E-01	8.44E-01
2.0	6.01E-02	4.78E-02	4.87E-02	8.92E-02	7.15E-01
3.0	5.47E-02	2.51E-02	4.66E-02	5.35E-02	6.18E-01
4.0	3.49E-02	1.79E-02	4.52E-02	3.41E-02	5.50E-01
5.0	2.25E-02	1.47E-02	4.40E-02	2.51E-02	4.99E-01
6.0	1.65E-02	1.26E-02	4.29E-02	2.04E-02	4.58E-01
7.0	1.33E-02	1.10E-02	4.18E-02	1.75E-02	4.22E-01
8.0	1.14E-02	9.62E-03	4.07E-02	1.52E-02	3.91E-01
9.0	9.89E-03	8.44E-03	3.97E-02	1.33E-02	3.63E-01
10.0	8.65E-03	7.41E-03	3.87E-02	1.17E-02	3.38E-01
15.0	4.56E-03	3.95E-03	3.40E-02	6.20E-03	2.45E-01
30.0	8.83E-04	8.04E-04	2.31E-02	1.24E-03	1.22E-01
45.0	3.06E-04	2.94E-04	1.57E-02	4.47E-04	7.22E-02
60.0	1.58E-04	1.55E-04	1.07E-02	2.33E-04	4.44E-02
90.0	5.53E-05	5.46E-05	4.94E-03	8.23E-05	1.72E-02
180.0	2.76E-06	2.72E-06	4.89E-04	4.10E-06	1.08E-03
365.0	6.56E-09	6.48E-09	4.20E-06	9.78E-09	5.37E-06

Mn-52: Injection, Adult Male

T(d)	- 24 h Excretion -		Retention			
	Fecal	Urine	Liver	Skelton	GI-Tract	W body
0.0	0.00E+00	0.00E+00	1.00E-01	7.00E-02	7.00E-02	1.00E+00
1.0	9.56E-03	2.48E-03	4.28E-01	8.33E-03	6.14E-02	8.71E-01
2.0	3.35E-02	4.73E-04	3.63E-01	8.42E-03	6.30E-02	7.35E-01
3.0	3.62E-02	4.24E-04	3.04E-01	8.36E-03	4.78E-02	6.13E-01
4.0	2.81E-02	3.64E-04	2.53E-01	8.16E-03	3.49E-02	5.13E-01
5.0	2.07E-02	3.07E-04	2.10E-01	7.85E-03	2.65E-02	4.32E-01
6.0	1.57E-02	2.57E-04	1.75E-01	7.45E-03	2.09E-02	3.66E-01
7.0	1.23E-02	2.14E-04	1.45E-01	7.00E-03	1.69E-02	3.11E-01
8.0	9.95E-03	1.78E-04	1.21E-01	6.52E-03	1.39E-02	2.64E-01
9.0	8.15E-03	1.49E-04	1.00E-01	6.03E-03	1.15E-02	2.25E-01
10.0	6.73E-03	1.24E-04	8.33E-02	5.54E-03	9.50E-03	1.92E-01
15.0	2.68E-03	5.01E-05	3.33E-02	3.41E-03	3.82E-03	8.79E-02
30.0	1.93E-04	3.74E-06	2.41E-03	5.83E-04	2.81E-04	9.48E-03
45.0	1.70E-05	3.41E-07	2.11E-04	8.47E-05	2.50E-05	1.14E-03
60.0	1.78E-06	3.69E-08	2.22E-05	1.17E-05	2.67E-06	1.46E-04
90.0	2.68E-08	5.67E-10	3.32E-07	2.11E-07	4.07E-08	2.53E-06
180.0	1.67E-13	3.49E-15	2.04E-12	1.28E-12	2.59E-13	1.54E-11
365.0	0.00E+00	0.00E+00	4.92E-25	3.47E-23	3.45E-25	2.79E-22

Mn-54: Injection, Adult Male

T(d)	- 24 h Excretion -		Retention			
	Fecal	Urine	Liver	Skelton	GI-Tract	W body
0.0	0.00E+00	0.00E+00	1.00E-01	7.00E-02	7.00E-02	1.00E+00
1.0	1.08E-02	2.80E-03	4.84E-01	9.41E-03	6.93E-02	9.83E-01
2.0	4.27E-02	6.03E-04	4.63E-01	1.07E-02	8.04E-02	9.37E-01
3.0	5.22E-02	6.11E-04	4.38E-01	1.20E-02	6.88E-02	8.82E-01
4.0	4.58E-02	5.92E-04	4.12E-01	1.33E-02	5.68E-02	8.34E-01
5.0	3.80E-02	5.64E-04	3.87E-01	1.44E-02	4.87E-02	7.94E-01
6.0	3.25E-02	5.33E-04	3.63E-01	1.55E-02	4.33E-02	7.59E-01
7.0	2.89E-02	5.02E-04	3.40E-01	1.64E-02	3.96E-02	7.28E-01
8.0	2.63E-02	4.72E-04	3.19E-01	1.73E-02	3.67E-02	7.00E-01
9.0	2.44E-02	4.44E-04	3.00E-01	1.80E-02	3.42E-02	6.73E-01
10.0	2.27E-02	4.18E-04	2.81E-01	1.87E-02	3.21E-02	6.49E-01
15.0	1.66E-02	3.10E-04	2.07E-01	2.11E-02	2.36E-02	5.45E-01
30.0	7.41E-03	1.43E-04	9.20E-02	2.24E-02	1.07E-02	3.64E-01
45.0	4.01E-03	8.08E-05	4.99E-02	2.02E-02	5.91E-03	2.72E-01
60.0	2.61E-03	5.42E-05	3.25E-02	1.72E-02	3.91E-03	2.15E-01
90.0	1.51E-03	3.21E-05	1.88E-02	1.20E-02	2.29E-03	1.44E-01
180.0	4.66E-04	9.95E-06	5.80E-03	3.99E-03	7.21E-04	4.71E-02
365.0	4.75E-05	1.02E-06	5.95E-04	5.76E-04	7.63E-05	5.62E-03

Ni-57: Injection, Adult Male

T(d)	- 24 h Excretion -		Retention			
	Fecal	Urine	Liver	Skelton	GI-Tract	W body
0.0	0.00E+00	0.00E+00	1.00E-01	7.00E-02	7.00E-02	1.00E+00
1.0	2.71E-03	2.65E-01	9.42E-03	3.06E-02	2.04E-02	3.36E-01
2.0	6.83E-03	4.68E-02	4.23E-03	1.02E-02	1.05E-02	1.53E-01
3.0	4.02E-03	1.48E-02	2.17E-03	3.55E-03	3.95E-03	7.61E-02
4.0	1.56E-03	4.73E-03	1.20E-03	1.34E-03	1.35E-03	4.11E-02
5.0	5.28E-04	1.53E-03	6.96E-04	5.56E-04	4.51E-04	2.36E-02
6.0	1.75E-04	5.14E-04	4.16E-04	2.58E-04	1.54E-04	1.40E-02
7.0	5.65E-05	1.76E-04	2.53E-04	1.32E-04	5.42E-05	8.56E-03
8.0	1.87E-05	6.34E-05	1.55E-04	7.27E-05	2.01E-05	5.28E-03
9.0	6.38E-06	2.45E-05	9.59E-05	4.21E-05	7.94E-06	3.27E-03
10.0	2.27E-06	1.01E-05	5.95E-05	2.51E-05	3.34E-06	2.04E-03
15.0	4.18E-08	3.62E-07	5.62E-06	2.25E-06	9.83E-08	1.95E-04
30.0	1.81E-11	1.98E-10	4.91E-09	1.97E-09	3.36E-11	1.71E-07
45.0	1.59E-14	1.75E-13	4.34E-12	1.78E-12	2.83E-14	1.52E-10
60.0	1.40E-17	1.55E-16	3.84E-15	1.61E-15	2.50E-17	1.34E-13
90.0	1.27E-24	1.39E-23	3.01E-21	1.30E-21	1.75E-24	1.05E-19
180.0	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00	0.00E+00

Re-183: Injection, Adult Male

T(d)	- 24 h Excretion -		Retention			
	Fecal	Urine	Thyroid	Liver	GI-Tract	W body
0.0	0.00E+00	0.00E+00	6.00E-04	1.00E-01	7.00E-02	1.00E+00
1.0	1.78E-02	1.44E-01	1.03E-02	2.10E-02	2.06E-01	8.29E-01
2.0	8.21E-02	1.03E-01	2.55E-03	1.48E-02	2.01E-01	6.36E-01
3.0	9.74E-02	6.72E-02	6.32E-04	1.07E-02	1.53E-01	4.65E-01
4.0	7.78E-02	4.49E-02	1.56E-04	7.88E-03	1.09E-01	3.38E-01
5.0	5.49E-02	3.06E-02	3.87E-05	5.96E-03	7.62E-02	2.49E-01
6.0	3.77E-02	2.12E-02	9.58E-06	4.61E-03	5.41E-02	1.88E-01
7.0	2.59E-02	1.49E-02	2.37E-06	3.66E-03	3.92E-02	1.45E-01
8.0	1.80E-02	1.06E-02	5.87E-07	2.98E-03	2.90E-02	1.15E-01
9.0	1.27E-02	7.76E-03	1.45E-07	2.48E-03	2.20E-02	9.36E-02
10.0	9.13E-03	5.75E-03	3.60E-08	2.10E-03	1.71E-02	7.78E-02
15.0	2.36E-03	1.73E-03	4.36E-11	1.15E-03	6.70E-03	3.98E-02
30.0	3.05E-04	2.77E-04	2.68E-20	4.50E-04	1.93E-03	1.48E-02
45.0	1.29E-04	1.22E-04	0.00E+00	2.34E-04	9.66E-04	7.68E-03
60.0	6.74E-05	6.44E-05	0.00E+00	1.25E-04	5.15E-04	4.11E-03
90.0	1.94E-05	1.86E-05	0.00E+00	3.61E-05	1.49E-04	1.19E-03
180.0	4.69E-07	4.47E-07	0.00E+00	8.70E-07	3.58E-06	2.85E-05
365.0	2.22E-10	2.12E-10	0.00E+00	4.12E-10	1.70E-09	1.35E-08

Tc-95m: Injection, Adult Male

	- 24 h Excretion -		Retention				
T(d)	Fecal	Urine	Thyroid	Liver	Skelton	GI-Tract	W body
0.0	0.00E+00	0.00E+00	6.00E-04	1.00E-01	7.00E-02	7.00E-02	1.00E+00
1.0	2.75E-02	2.12E-01	5.18E-03	2.41E-02	4.98E-02	3.69E-01	7.45E-01
2.0	1.33E-01	4.35E-02	2.64E-03	1.20E-02	3.95E-02	2.88E-01	5.58E-01
3.0	1.44E-01	2.27E-02	1.60E-03	9.88E-03	3.00E-02	1.77E-01	3.86E-01
4.0	9.56E-02	1.64E-02	1.07E-03	8.67E-03	2.27E-02	1.05E-01	2.70E-01
5.0	5.65E-02	1.23E-02	7.59E-04	7.74E-03	1.73E-02	6.75E-02	1.98E-01
6.0	3.50E-02	9.27E-03	5.55E-04	6.99E-03	1.32E-02	4.67E-02	1.52E-01
7.0	2.34E-02	7.00E-03	4.13E-04	6.38E-03	1.02E-02	3.39E-02	1.20E-01
8.0	1.68E-02	5.31E-03	3.11E-04	5.87E-03	7.87E-03	2.53E-02	9.65E-02
9.0	1.24E-02	4.05E-03	2.36E-04	5.45E-03	6.17E-03	1.91E-02	7.90E-02
10.0	9.33E-03	3.10E-03	1.80E-04	5.08E-03	4.89E-03	1.45E-02	6.57E-02
15.0	2.50E-03	9.38E-04	5.42E-05	3.81E-03	1.94E-03	4.17E-03	3.29E-02
30.0	2.95E-04	1.56E-04	9.01E-06	1.90E-03	8.62E-04	6.11E-04	1.31E-02
45.0	1.38E-04	7.55E-05	4.37E-06	9.73E-04	6.85E-04	2.92E-04	6.89E-03
60.0	7.04E-05	3.86E-05	2.23E-06	4.98E-04	5.60E-04	1.50E-04	3.74E-03
90.0	1.86E-05	1.02E-05	5.88E-07	1.31E-04	3.85E-04	3.93E-05	1.22E-03
180.0	3.83E-07	2.10E-07	1.22E-08	2.39E-06	1.33E-04	8.15E-07	1.48E-04
365.0	2.80E-09	1.63E-09	9.48E-11	1.92E-09	1.54E-05	6.19E-09	1.54E-05

Tc-95: Injection, Adult Male

T(d)	- 24 h Excretion -		-----		Retention	-----	
	Fecal	Urine	Thyroid	Liver	Skelton	GI-Tract	W body
0.0	0.00E+00	0.00E+00	6.00E-04	1.00E-01	7.00E-02	7.00E-02	1.00E+00
1.0	1.21E-02	9.33E-02	2.28E-03	1.06E-02	2.19E-02	1.62E-01	3.28E-01
2.0	2.59E-02	8.49E-03	5.14E-04	2.34E-03	7.67E-03	5.60E-02	1.09E-01
3.0	1.23E-02	1.96E-03	1.38E-04	8.49E-04	2.57E-03	1.52E-02	3.31E-02
4.0	3.61E-03	6.25E-04	4.07E-05	3.28E-04	8.57E-04	3.99E-03	1.02E-02
5.0	9.39E-04	2.06E-04	1.27E-05	1.29E-04	2.88E-04	1.13E-03	3.31E-03
6.0	2.62E-04	6.93E-05	4.10E-06	5.13E-05	9.69E-05	3.44E-04	1.12E-03
7.0	7.68E-05	2.30E-05	1.35E-06	2.06E-05	3.29E-05	1.10E-04	3.88E-04
8.0	2.42E-05	7.68E-06	4.47E-07	8.35E-06	1.12E-05	3.63E-05	1.38E-04
9.0	7.89E-06	2.58E-06	1.49E-07	3.41E-06	3.88E-06	1.21E-05	4.97E-05
10.0	2.59E-06	8.61E-07	5.04E-08	1.40E-06	1.35E-06	4.05E-06	1.82E-05
15.0	1.34E-08	5.25E-09	3.09E-10	1.86E-08	9.93E-09	2.36E-08	1.66E-07
30.0	7.05E-15	3.68E-15	2.18E-16	3.96E-14	1.82E-14	1.49E-14	2.76E-13
45.0	1.79E-20	9.23E-21	3.73E-22	9.13E-20	6.41E-20	2.52E-20	6.44E-19
60.0	0.00E+00	0.00E+00	0.00E+00	2.04E-25	2.25E-25	0.00E+00	1.42E-24

Tc-96: Injection, Adult Male

T(d)	- 24 h Excretion -		-----		Retention	-----	
	Fecal	Urine	Thyroid	Liver	Skelton	GI-Tract	W body
0.0	0.00E+00	0.00E+00	6.00E-04	1.00E-01	7.00E-02	7.00E-02	1.00E+00
1.0	2.36E-02	1.82E-01	4.46E-03	2.07E-02	4.28E-02	3.17E-01	6.41E-01
2.0	9.88E-02	3.22E-02	1.95E-03	8.89E-03	2.92E-02	2.13E-01	4.13E-01
3.0	9.16E-02	1.45E-02	1.02E-03	6.30E-03	1.91E-02	1.13E-01	2.46E-01
4.0	5.24E-02	9.01E-03	5.89E-04	4.75E-03	1.24E-02	5.78E-02	1.48E-01
5.0	2.66E-02	5.80E-03	3.58E-04	3.65E-03	8.14E-03	3.18E-02	9.35E-02
6.0	1.42E-02	3.77E-03	2.25E-04	2.84E-03	5.36E-03	1.89E-02	6.17E-02
7.0	8.19E-03	2.45E-03	1.44E-04	2.23E-03	3.54E-03	1.19E-02	4.19E-02
8.0	5.04E-03	1.60E-03	9.35E-05	1.76E-03	2.37E-03	7.60E-03	2.90E-02
9.0	3.21E-03	1.05E-03	6.11E-05	1.41E-03	1.59E-03	4.94E-03	2.04E-02
10.0	2.07E-03	6.89E-04	4.02E-05	1.13E-03	1.09E-03	3.24E-03	1.46E-02
15.0	2.66E-04	1.01E-04	5.81E-06	4.00E-04	2.04E-04	4.47E-04	3.46E-03
30.0	3.31E-06	1.74E-06	1.01E-07	2.08E-05	9.45E-06	6.87E-06	1.43E-04
45.0	1.61E-07	8.82E-08	5.12E-09	1.11E-06	7.84E-07	3.43E-07	7.90E-06
60.0	8.61E-09	4.72E-09	2.74E-10	5.96E-08	6.69E-08	1.83E-08	4.48E-07
90.0	2.48E-11	1.35E-11	7.86E-13	1.71E-10	5.01E-10	5.27E-11	1.59E-09
180.0	9.05E-19	4.92E-19	2.87E-20	4.26E-18	2.25E-16	1.94E-18	2.53E-16